

---

**PD1100 PASS-THROUGH  
ALPHANUMERIC  
POLE DISPLAY**

---

**PROGRAMMING &  
USER'S GUIDE**



## Forward

The information contained in this user's guide is subject to change without notice.

This Programming and User's Guide was prepared by Ultimate Technology Corporation (UTC) for use by its customers, dealers, and affiliates. All attempts have been made to ensure that the information presented in this manual is correct. No liability expressed or implied, will be assumed by UTC, its dealers or affiliates for damage resulting from the use of this information.

If the dealer cannot answer your questions, please call Customer Service, Ultimate Technology: (800) 348-0546.

If a unit needs to be shipped to UTC for repairs, please return it in the original packing material and shipping container. It is recommended that one set of packing material be saved for this purpose.

**NOTE:** This equipment has been tested and found to comply with the limits for a Class "A" digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

## Table of Contents

<b><u>SECTION 1</u></b>	<b>PRODUCT INTRODUCTION.....</b>	<b>1-1</b>
	Product Overview.....	1-1
	General Specifications.....	1-1
	Features.....	1-1
	You Can Do It!.....	1-2
	Using This Manual.....	1-2
	Customer Support.....	1-2
<b><u>SECTION 2</u></b>	<b>INSTALLATION.....</b>	<b>2-1</b>
	Unpacking.....	2-1
	Testing.....	2-1
	Mounting.....	2-1
	Option One.....	2-1
	Option Two.....	2-2
	Serial / Parallel Connection.....	2-3
	Power Up.....	2-3
<b><u>SECTION 3</u></b>	<b>PROGRAMMING.....</b>	<b>3-1</b>
	Introduction.....	3-1
	Setup.....	3-2
	Operating Modes.....	3-3
	Display Control Command.....	3-3
	Top Line Message.....	3-3
	Bottom Line Message.....	3-4
	Top Line Continuous Scrolling.....	3-4
	Set/Time Display.....	3-4
	Top Line 1 Time Scroll.....	3-4
	Disable Menu Buttons.....	3-4
	Brightness.....	3-4
	Back Spacing.....	3-5
	Horizontal Tab.....	3-5
	Line Feed.....	3-5
	Carriage Return.....	3-7
	Display Position.....	3-7
	Normal Display Mode.....	3-7
	Vertical Scroll Mode.....	3-7
	Pass-Through Mode.....	3-7
	Direct To Pole Mode.....	3-8
	Reset Display.....	3-8
	Flashing Text Start.....	3-9
	Flashing Text End.....	3-9
	Clear To End of Line.....	3-9
	Clear To End of Display.....	3-9

Select Font .....	3-9
Clear Display .....	3-10
Down Line Load .....	3-10
Redefine Graphic .....	3-12
Send Version String .....	3-12

<b>SECTION 4 TECHNICAL INFORMATION .....</b>	<b>4-1</b>
Cable Pinouts.....	4-1
ASCII Character Set .....	4-3

### List of Tables

Table 3-1	The PD1100 Pass-Through Display Functions.....	3-1
Table 3-2	Setup Menu and Program Parameters .....	3-2
Table 3-3	Display Brightness Control Commands .....	3-5
Table 3-4	Command Set Data .....	3-11

### List of Figures

Figure 2-1	Free Standing Pole Display .....	2-1
Figure 2-2	Stand Alone Pole Display .....	2-2
Figure 2-3	Inserted Pole Display .....	2-2
Figure 2-4	Typical PD1100 Pass-Through Serial/Parallel Connections.....	2-3
Figure 2-5	PD1100 Pass-Through Pole Display Unit.....	2-4
Figure 3-1	Entering the Setup Menu Program .....	3-3
Figure 4-1	Typical Serial Pinouts .....	4-1
Figure 4-2	Typical Parallel Pinouts .....	4-2

## **Section 1 PRODUCT INTRODUCTION**

### **Product Overview**

Congratulations on the purchase of your new PD1100 PASS-THROUGH Pole Display. Please take a few minutes to read this section. It is designed to introduce you to your new pole display, and this user's guide. After reading this section, you will have a better understanding of what you need to know about the PD1100 PASS-THROUGH, as well as how to find the information you need.

The PD1100 PASS-THROUGH is a 2 line, 20 character per line, Vacuum Fluorescent Display (VFD) unit attached to a pole-mounting base. The display unit operates by converting specific commands, from any serial or parallel-communicating device, into an alphanumeric display.

The PD1100 PASS-THROUGH was designed to connect directly to a personal computer COM 1 or COM 2 port, serial receipt printer, serial ASCII terminal auxiliary port, or any device that supports a Centronics parallel port.

The PD1100 PASS-THROUGH is available in either an RS232 serial interface, with selectable baud rates, or a Centronics parallel interface. Both serial and parallel interfaces operate in the Direct To Pole or UTC Pass-Through, and support the Pass-Through feature.

The Pass-Through feature provides the ability to pass data through the display unit directly to another device that has a serial or parallel communications port. When this feature is selected, the display unit appears to be a straight through cable, having no effect on the transmitted data. This feature allows an additional device to be connected without requiring another parallel or serial port on the host computer or terminal.

The PD1100 PASS-THROUGH allows you to set up and alter the parameters of the display unit through the use of two buttons located on the underside of the display. The RS232 model comes factory set at; **4800 bps, 8 data bits, and no parity.**

## General Specifications

Number of Characters .....	2 rows of 20 characters
Character Configuration .....	5x7 Dot Matrix
Character Set .....	ASCII
Character Height .....	10.5 mm
Character Width.....	5.5 mm
Character Pitch.....	7.4 mm
Peak Wave Length of Illumination .....	Green (505 nm)
Luminance .....	690 cd/m <sup>2</sup> (204fL)
Height .....	23"
Weight .....	2.50 lbs.
Width .....	8.75"
Depth .....	1.80"
Operating Temperature .....	0 to 50 degrees C
Storage Temperature .....	-20 to +70 degrees C
Relative Humidity.....	90% Non-Condensing
Power Requirements .....	+9 VDC @ 1.2 amp

## Features

- 360 Degree Rotation
- 10 Degree Bi-directional Tilt
- RS232 Serial or Parallel Interface
- Direct to Pole, UTC Pass-Through
- 2 Line – 20 character/Line Display
- 4 Programmable Display Intensities
- Menu-Driven Setup
- Supports Six International Character Sets
- Vertical and Horizontal Scrolling
- Top or Bottom Line Messages
- Flashing Messages
- Top Line Scrolling
- 16 Selectable Baud Rates
- Optional Parity Generation
- Time/Clock Display
- 96 Display Characters
- Optional Pole Height Available
- Non-volatile Parameter Storage
- Downloadable Character Sets
- Downloadable Setup Parameters

## **You Can Do It!**

The PD1100 PASS-THROUGH Pole Display permits you to easily set up and install the pole display by following the instructions in this manual. No special training or tools are necessary.

## **Using This Manual**

This Programming and User's Guide contains information on the installation and programming of your PD1100 PASS-THROUGH Pole Display. It is suggested that the entire manual be read before attempting installation or programming.

## **Customer Support**

If you are unable to resolve a problem after reading and reviewing this manual, contact Customer Service:

Ultimate Technology Corporation  
100 Rawson Road  
Victor, New York 14564  
Phone: (800) 349-0546  
Fax: (585) 924-1434

## **Section 2**    **INSTALLATION**

### **Unpacking**

The PD1100 PASS-THROUGH is shipped in a strong, lightweight cardboard container. The components are packed in foam padding which protects them during shipping.

**Note:**    Check packaging for water or physical damage and notify your carrier immediately if any damage is evident. Carefully remove the components from the box. Keep original packing material in case the PD1100 PASS-THROUGH needs to be shipped to another location.

### **Testing**

A diskette has been provided for testing your PD1100 PASS-THROUGH. To test the PD1100 PASS-THROUGH using the UTC provided test program, a PC with a BASIC language program will be required. The diskette contains a “README” file with instructions on running the test program.

### **Mounting**

The PD1100 PASS-THROUGH comes with a mounting device, consisting of a mounting bracket and mounting plate. The mounting device can be utilized in a variety of ways. Review the following options and select the option that best suits your application.

**Note:**    Before proceeding any further, be sure that the computer terminal or device you are connecting to is powered off. To ensure a power-off state, remove the device from its power source.

#### Option One:

This option, shown in Figure 2-1, allows the user to place the pole display, with mounting bracket and plate attached, under a cash drawer or computer terminal.




Figure 2-1    Free Standing Pole Display



Option Two:

This option, shown in Figure 2-2, allows the user to install the pole display in a variety of ways. You may choose to install the display unit using just the mounting bracket, or with the mounting bracket attached to the center position of the mounting plate.




Figure 2-2 Stand Alone Pole Display

After determining which option best suits your needs, begin the installation. Insert the interface cables, which come out of the bottom of the PD1100 PASS-THROUGH pole display, through the top of the mounting bracket. Insert the pole into the mounting bracket using a back and forth twisting motion to ensure a secure fit. Ensure that cable(s) clear all obstructions while inserting the pole into mounting bracket. Avoid placing pressure of any kind on the display head. The pole should be inserted until it reaches the bottom stop. The stop, as shown in Figure 2-3, is located  $\frac{1}{4}$ " from the bottom of the bracket.




Figure 2-3 Inserted Pole Display

## Serial / Parallel Connection

Attach the output and input connectors of the PD1100 PASS-THROUGH as shown in Figure 2-4. Now you are ready to perform the Power Up procedure.




Figure 2-4 Typical PD1100 PASS-THROUGH Serial/Parallel Connections

## Power Up

Place the wall transformer into a 120 volt AC power source.

A message appears on the display window and remains for a few seconds. This message is an indication of a successful power up.

*First Message*




Figure 2-5 The PD1100 PASS-THROUGH Pole Display Unit

## Section 3 PROGRAMMING

### Introduction

The PD1100 PASS-THROUGH Pole Display operates by converting data supplied by a specific device into a displayed message. The supplied data may also contain commands that alter the way the message is displayed. The altered display functions vary, depending on the operating mode of the display unit. Table 3-1 lists the display functions and their availability with the operating modes of the PD1100 PASS-THROUGH.

The operating mode, along with program parameters, is selected at setup. PD1100 PASS-THROUGH setup and display control commands with descriptions are given in this section.

Table 3-1 The PD1100 PASS-THROUGH Display Functions

DISPLAY FUNCTION		UTC PASS-THROUGH MODE	DIRECT TO POLE MODE
(1)	TOP LINEMESSAGE	<ESC>uA	N/A
(2)	BOTTOM LINE MESSAGE	<ESC>uB	N/A
(3)	TOP LINE CONTINUOUS SCROLLING	<ESC>uD	N/A
(4)	SET/DISPLAY TIME	<ESC>uE	N/A
(5)	TOP LINE 1 TIME SCROLL	<ESC>uF	N/A
(6)	DISPLAY MENU BUTTONS	<ESC>uG<CR>	N/A
(7)	BRIGHTNESS	N/A	<EOT>x
	x = 20h Dim            x = 60h Medium		
	x = 40h Low            x = FFh High		
(8)	BACK SPACING	N/A	<BS>
(9)	HORIZONTAL TAB	N/A	<HT>
(10)	LINE FEED	N/A	<LF>
(11)	CARRIAGE RETURN	N/A	<CR>
(12)	DISPLAY POSITION	N/A	<DLE>
(13)	NORMAL DISPLAY MODE	N/A	<DC1>
(14)	VERTICAL SCROLL MODE	N/A	<DC2>
(15)	PASS-THROUGH MODE	N/A	<ESC>d*
(16)	DIRECT TO POLE MODE	<ESC><RS>*	N/A
(17)	RESET DISPLAY	N/A	<US>
(18)	FLASHING TEXT START	<SI>	<FS>
(19)	FLASHING TEXT END	<SO>	<GS>
(20)	CLEAR TO END OF LINE	N/A	<CAN>
(21)	CLEAR TO END OF DISPLAY	N/A	<EM>
(22)	DISPLAY FONTS	<ESC>ulx<CR>	<SUB>x
	x = 01h American    x = 05h French		
	x = 02h British            Canadian		
	x = 03h German        x = 06h Spanish		
	x = 04h French        x = 07h PD220XL		
(23)	CLEAR DISPLAY	<ESC>uA<CR><ESC>uB<CR>	<RS>
(24)	DOWN LINE LOAD	<ESC>utc	N/A
(25)	REFEFINE GRAPHIC	<ESC>uH	N/A
(26)	SEND VERSION STRING	<ESC>uJ<CR>	N/A

\*These (<RS> and 'd') can be changed in configuration to a user specified code.

## Setup

Upon successful system Power Up, as described in Section 2, you can begin the PD1100 PASS-THROUGH Setup Menu Program. To enter the program, press both Menu Select buttons simultaneously. A message will appear on the display as described in Power Up. The Setup Menu Program is also used to change program parameters. Table 3-2 lists the menu items and program parameters accessed through the Setup Menu.

Pressing the right button (Menu Select #1), allows you to scroll through the menu items. Pressing the left button (Menu Select #2), allows you to scroll through the options. Refer to Figure 3-1.

Stopping at an option and pressing the right button, selects that option and moves the display to the next menu item. Upon completion and exiting the sequence, a message is given and within five (5) seconds the display goes blank.

Table 3-2 Setup Menu and Program Parameters

MENU ITEMS	OPTIONS
1. RESET DEFAULTS	YES, NO*
2. BAUD RATE	300, 600, 900, 1200, 1800, 2400, 2880, 3600, 4800*, 6400, 7200, 9600 14.4k, 19.2k, 28.8k, 57.6k bps
3. PARITY	NONE*, EVEN, ODD, MARK, SPACE
4. BRIGHTNESS	DIM, LOW, MEDIUM*, HIGH
5. START UP MODE	DIRECT TO POLE, UTC PASS-THROUGH*, EMAX SUBSET
6. PASS-THROUGH ON CODE	00h-7Fh (Hex Code – 64)*
7. DIRECT TO POLE ON CODE	00h-7Fh (Hex Code – 1E)*
8. OUTPUT PORT	ENABLED*, DISABLED
9. COMMAND TERMINATOR	CR ONLY*, LF ONLY, CR/LF PAIR
10. HANDSHAKING	HARDWARE*, DISABLED
11. CHARACTER SET	PD220XL*, AMERICAN, BRITISH, GERMAN, FRENCH, SPANISH, FRENCH CANADIAN
12. SAVE CHANGES NOW? (Write to nvram now?)	YES, NO*
13. EXIT SETUP NOW?	YES*, NO

\*Default setting for each menu item in nonvolatile memory.




Figure 3-1 Entering the Setup Menu Program

## Operating Modes

The **UTC Pass-Through Mode** allows for all data to pass through to an attached device while allowing certain customer display commands to be active. Refer to Table 3-1 for display functions available with specific operating modes.

The **Direct To Pole Mode** allows direct communications to the pole only. To output to a second device, a software switch to UTC Pass-Through Mode should be used with a software switch back when pole output is again desired. Software switches are described in Section 3 under Display Control Command, items 15 (PASS-THROUGH MODE), and 16 (DIRECT TO POLE MODE).

## Display Control Command

The following describes all display control features along with an example of their command and data sequence. When the control feature is available for UTC Pass-Through Mode, an example of the UTC command and data sequence is given.

1.     <ESC>uAxxx...xxx<CR>                   TOP LINE  
  ALPHANUMERIC

The leftmost 20 characters, following the command terminated by a CR (Carriage Return), will be displayed on the top line.

**NOTE:** To clear top line use: <ESC>uA<CR>

2. <ESC>uBxxx...xxx<CR> BOTTOM LINE  
ALPHANUMERIC

The leftmost 20 characters, following the command terminated by a CR (Carriage Return), will be displayed on the bottom line.

**Note:** To clear bottom line use: <ESC>uB<CR>  
This will remove time from the display but the internal clock will continue to run.

3. <ESC>uDxxx...xxx<CR> TOP LINE  
ONGOING ALPHANUMERIC  
MESSAGE SCROLL

A message of up to 40 characters will be scrolled continuously on the top line of the display.

4. <ESC>uEhh:mm<CR> TIME DISPLAY  
BOTTOM LINE

Time value (12 hour clock) will be shown on the bottom line in the format hh:mm:ss and continuously updated until cleared by a command to write to the bottom line.

**Note:** To re-display previously set time use: <ESC>uE<CR>

5. <ESC>uFxxx...xxx<CR> TOP LINE 1 TIME  
ALPHANUMERIC  
MESSAGE SCROLL

A message of up to 40 characters will scroll once on the top line.

6. <ESC>uG<CR> DISABLE MENU BUTTONS  
UNTIL NEXT POWER UP

7. ASCII      HEX      DEC  
<EOT>x      04      04      BRIGHTNESS

Upon receipt of a dimming command, subsequent characters will be at the brightness level selected. This level will remain until a new dimming command is received. Where x is the option byte:

x	=	Dim 20h	Low 40h	Medium 60h	High FFh
---	---	------------	------------	---------------	-------------

Table 3-3 Display Brightness Control Commands

Dimming Level	ASCII	DEC	HEX
100 %	-	255	FF
60 %	`	96	60
40 %	@	64	40
20 %	Space	32	20

8.     **ASCII**       **HEX**     **DEC**  
       <BS>        08h        08            BACK SPACING

When the backspace command is executed the cursor position is shifted to the left one position, erasing the character, if any, that was in that position. When the cursor is in the first (read from left to right) position of the first row, the cursor moves to the last position of the second row. When the cursor is in the first position of the second row, the cursor moves to the last position of the first row.

9.     **ASCII**       **HEX**     **DEC**  
       <HT>        09h        09            HORIZONTAL TAB

**DC1 MODE**  
 (Normal Display Mode)

The cursor position is shifted to the right one position. When the cursor is in the last position of the first row, the cursor moves to the first position of the second row. When the cursor is in the last position of the second row, the cursor moves to the first position of the first row.

**DC2 MODE**  
 (Vertical Scroll Mode)

When the cursor is in the last position of the second row, the characters displayed in the second row are shifted up to the first row and the cursor moves to the first position of the second row. This clears the second row.

10.    **ASCII**       **HEX**     **DEC**  
       <LF>        0Ah        10            LINE FEED

**DC1 MODE**  
 (Normal Display Mode)

The cursor moves up or down to the other row, staying in the same position.



### DC2 MODE

(Vertical Scroll Mode)

When the cursor is in the second row, the character displayed there is shifted up to the first row, leaving the cursor at its present position. This clears the second row. When the cursor is in the first row, the cursor moves down to the second row.

11.     ASCII            HEX     DEC  
       <CR>            ØDh     13                    CARRIAGE RETURN

The cursor moves to the first position of the same row.

12.     ASCII            HEX     DEC  
       <DLE>           1Øh     16                    DISPLAY POSITION

By using the display positioning function, the write-in starting position can be specified. After writing 10h to prepare the display for this command, another HEX byte is written to specify the position desired. A third byte representing data is then sent.

#### Character Position Chart (HEX)

#### ROW

1	00	01	02	03	04	05	06	07	08	09	0A	0B	0C	0D	0E	0F	10	11	12	13
2	14	15	16	17	18	19	1A	1B	1C	1D	1E	1F	20	21	22	23	24	25	26	27

13.     ASCII            HEX     DEC  
       <DC1>           11h     17                    NORMAL DISPLAY MODE

After writing a character, the cursor is shifted automatically to the right one position. When the cursor is in the last position of the first row, it moves to the first position of the second row. When the cursor is on the last position of the second row, the cursor moves to the first position of the first row.

14.     ASCII            HEX     DEC  
       <DC2>           12h     18                    VERTICAL SCROLL MODE

After writing the characters up to the last position of the second row, all characters displayed in the second row are shifted to the upper row (first row), clearing the second row. The Vertical Scroll Mode (DC2) is the default mode preset by the factory, and will be held until another mode is selected.

15.     <ESC>d\*                                    PASS-THROUGH MODE

This command is used in Direct To Pole Mode to begin passing data through to the attached device. After this command is received, the display will be in UTC Pass-Through Mode.

To pass an <ESC>u sequence thru to the attached device, when in UTC Pass-Through Mode, send two <ESC>'s [i.e. <ESC><ESC>u..] and the data received by the device will be a single <ESC>u. If the escape sequence to be sent through does not begin with { 'u' or '<RS>' } then 2 escapes are not needed.

If **<ESC><RS>** must be sent to the printer then two options are possible:

Option 1:

Redefine the Direct To Pole Mode character to another code in lieu of **<RS>**.

Option 2:

Send **<ESC><ESC><RS>** and the device will receive **<ESC><RS>**.

*\*The Pass-Through Mode command may be changed on the setup menu to any character, in the range 00h through 7Fh.*

16. **<ESC><RS>\*** DIRECT TO POLE MODE

This command is used in UTC Pass-Through Mode to enter or return to Direct To Pole Mode. If any UTC Pass-Through Mode display commands have been used (other than Pass-Through data), the display will be cleared and reset to the last mode used in Direct To Pole Mode or to the default **<DC2>** (Vertical Scroll Mode).

If Pass-Through data is desired, use the command **<ESC>d** to enter UTC Pass-Through Mode, send data to the attached device, then switch back to Direct To Pole Mode with **<ESC><RS>**.

**Note:** To enter UTC Pass-Through Mode from Direct To Pole Mode, send a **<ESC>d\*** or specify during setup. To enter Direct To Pole Mode from UTC Pass-Through Mode, send a **<ESC><RS>\*** or specify during setup. In order to direct output to printer, a software switch to UTC Pass-Through Mode should be used with a software switch back when pole output is again desired.

*\* These commands may be changed on the setup menu to any character except 'u' in the range 00h to 7Fh.*

17. 

<b><u>ASCII</u></b>	<b><u>HEX</u></b>	<b><u>DEC</u></b>	
<b>&lt;US&gt;</b>	<b>1Fh</b>	<b>31</b>	<b>RESET DISPLAY</b>

The display will be cleared and reset to the default of **<DC2>** mode (Vertical Scroll). The cursor will be positioned to the first position on the top line.

**Note:** Since this command resets the display modes, if you wish to continue to use the display in **<DC1>** and/or **<DC2>** modes, you must reissue those commands after **<US>**.

18.	<u>ASCII</u> <SI> <FS>	<u>HEX</u> ØFh 1Ch	<u>DEC</u> 15 28	FLASHING TEXT START in Pass-Through Mode in Direct To Pole Mode
-----	------------------------------	--------------------------	------------------------	---

19.	<u>ASCII</u> <SO> <GS>	<u>HEX</u> ØEh 1Dh	<u>DEC</u> 14 29	FLASHING TEXT END in Pass-Through Mode in Direct To Pole Mode
-----	------------------------------	--------------------------	------------------------	---

These commands are used inside top and bottom line display commands in UTC Pass-Through Mode to flash text on the display. By surrounding the text to flash with **<SI> CTRL-O** and **<SO>CTRL-N** the text in between will flash.

Example in UTC Pass-Through Mode only:

**<ESC>uD SPECIAL ON WIDGETS ONLY <SI>3.99<SO> PER POUND.<CR>**

Example in Direct To Pole Mode only:

**<US> SPECIAL ON WIDGETS <CR> <LF> ONLY <FS> 3.99  
<GS> PER POUND.**

20.	<u>ASCII</u> <CAN>	<u>HEX</u> 18	<u>DEC</u> 24	CLEAR TO END OF LINE
-----	-----------------------	------------------	------------------	----------------------

This command will clear out the display from the current write-in position to the end of the current line. The current write-in position will not change.

Direct to Pole Mode Only

21.	<u>ASCII</u> <EM>	<u>HEX</u> 19	<u>DEC</u> 25	CLEAR TO END OF DISPLAY
-----	----------------------	------------------	------------------	-------------------------

This command will clear out the display from the current write-in position to the end of the second line. The current write-in position will not change.

Direct to Pole Mode Only

22.	<ESC>ul n <CR> n is ASCII digit '1' – '7'	SELECT FONT 1 American 2 British 3 German 4 French 5 French Canadian 6 Spanish 7 PD220XL
-----	--	---

- |     |                      |                   |                  |               |
|-----|----------------------|-------------------|------------------|---------------|
| 23. | <u>ASCII</u><br><RS> | <u>HEX</u><br>1Eh | <u>DEC</u><br>30 | CLEAR DISPLAY |
|-----|----------------------|-------------------|------------------|---------------|


These commands are used to clear the display and move the cursor to the home position without changing any modes in effect.

- |     |                         |                |
|-----|-------------------------|----------------|
| 24. | <ESC>utc{selection}<CR> | DOWN LINE LOAD |
|-----|-------------------------|----------------|

In UTC Pass-Through Mode, the display can download the setup options without having to traverse through the setup menu manually. This command is useful when multiple displays are to be set up. Refer to Table 3-3 for the selections and data than can be entered into the download command set. The xx are substituted by the specific value required.

**EXAMPLE:**

To set Baud Rate to 9600 and Contrast to #####, send:

<ESC>utc A0B C03<CR>	
	<b>CONTRAST</b> <b>BAUD RATE</b> <b>DOWNLOAD ENABLE COMMAND</b>

These will be the only parameters changed.

Table 3-4 Command Set Data

<b>SELECTION</b>		<b>BAUD RATE</b>	<b>xx</b>	<b>BAUD RATE</b>	<b>xx</b>
Parallel	Serial				
N/A	Axx	300	00	*4800	08
		600	01	6400	09
		900	02	7200	0A
		1200	03	9600	0B
		1800	04	14.4K	0C
		2400	05	19.2K	0D
		2800	06	28.8K	0E
		3600	07	57.6K	0F
<b>SELECTION</b>		<b>PARITY</b>	<b>xx</b>	<b>PARITY</b>	<b>xx</b>
Parallel	Serial				
N/A	Bxx	*NONE	00	MARK	03
		EVEN	01	SPACE	04
		ODD	02		
<b>SELECTION</b>		<b>CONTRAST</b>	<b>xx</b>	<b>CONTRAST</b>	<b>xx</b>
Parallel	Serial				
Cxx	Cxx	#	00	*###	02
		##	01	####	03
<b>SELECTION</b>		<b>START UP MODE</b>			<b>xx</b>
Parallel	Serial				
Dxx	Dxx	*UTC PASS-THROUGH MODE			00
		DIRECTED TO POLE MODE			01
		EMAX SUBSET			02
<b>SELECTION</b>		<b>PASS-THROUGH ON CODE</b>			<b>xx</b>
Parallel	Serial				
Exx	Exx	Xx=00h to 7Fh			64h
<b>SELECTION</b>		<b>DIRECT TO POLE ON CODE</b>			<b>xx</b>
Parallel	Serial				
Fxx	Fxx	Xx=00h to 7Fh			30h
<b>SELECTION</b>		<b>OUTPUT PORT</b>			<b>xx</b>
Parallel	Serial				
Gxx	Gxx	DISABLED			00
		*ENABLED			01
<b>SELECTION</b>		<b>TERMINATOR CHARACTER</b>			<b>xx</b>
	Serial				
	Hxx	CR			00
		LF			01
		CR/LF			02
<b>SELECTION</b>		<b>HANDSHAKE</b>			<b>xx</b>
	Serial				
	Ixx	Disabled			00
		Enabled			01

\*Default settings or parameters outside of above specified ranges.

25. <ESC>uH REDEFINE GRAPHIC  
 cc H1 H2 H3 H4 H5 H6 H7>RET>  
 (cc = character to change in Hex)

Allows the generation of custom character graphics. Defined below is the creation of a character "A".

**CHARACTER DOT POSITION**

	7	6	5	4	3	2	1	0	
	0	1	0	○	○	●	○	○	H1
	0	1	0	○	●	○	●	○	H2
	0	1	0	●	○	○	○	●	H3
	0	1	0	●	○	○	○	●	H4
	0	1	0	●	●	●	●	●	H6
	0	1	0	●	○	○	○	●	H6
	0	1	0	●	○	○	○	●	H7

	7	6	5	4	3	2	1	0			
H1	=	0	1	0	0	0	1	0	0	or	44h
H2	=	0	1	0	0	1	0	1	0	or	4Ah
H3	=	0	1	0	1	0	0	0	1	or	51h
H4	=	0	1	0	1	0	0	0	1	or	51h
H5	=	0	1	0	1	1	1	1	1	or	5Fh
H6	=	0	1	0	1	0	0	0	1	or	51h
H7	=	0	1	0	1	0	0	0	1	or	51h

26. <ESC>uJ SEND VERSION STRING

Sent to Pass-Through device.

Example: *printer*.

## **Section 4 TECHNICAL INFORMATION**

### **Cable Pinouts**


The PD1100 PASS-THROUGH Pole Display cable connections can be configured to user specifications. Figures 4-1 and 4-2 show typical RS232 (serial) and Centronics (parallel) pinout data.

**Note:** All signals, except for TX, RX and DTR, are passed directly through. DTR is the only handshaking line monitored.

If the output cable is not connected to a modem or printer, it may be necessary to jump pins 4 to 5, and 6 to 20 in order to satisfy handshaking in your computer.

### **Serial Pinouts**

#### **PD1100 PASS-THROUGH-Serial**




#### **DB25 Male**

	<i>Input</i>		<i>Output</i>
1	Chassis Ground	1	Chassis Ground
2	TX Data	2	RX Data
3	RX Data	3	TX Data
4	RTS	4	RTS
5	CTS	5	CTS
6	DSR	6	DSR
7	Signal Ground	7	Signal Ground
8	DCD	8	DCD
20	DTR	20	DTR

Figure 4-1 Typical Serial Pinouts



## Parallel Pinouts



1	Strobe	10	ACK
2	Data 0	11	Busy
3	Data 1	12	Paper End (Low)
4	Data 2	13	Sict
5	Data 3	14	Auto LF
6	Data 4	15	Error
7	Data 5	16	Init
8	Data 6	17	Sict In
9	Data 7	20-24	Signal Ground

Figure 4-2 Typical Parallel Pinouts

## ASCII Character Set

DEC	HEX	ASCII	DEC	HEX	ASCII	DEC	HEX	ASCII	DEC	HEX	ASCII
0	00	Ctrl-@ (NUL)	32	20	Space	64	40	@	96	60	`
1	01	Ctrl-A (SOH)	33	21	!	65	41	A	97	61	a
2	02	Ctrl-B (STX)	34	22	"	66	42	B	98	62	b
3	03	Ctrl-C (ETX)	35	23	#	67	43	C	99	63	c
4	04	Ctrl-D (EOT)	36	24	\$	68	44	D	100	64	d
5	05	Ctrl-E (ENQ)	37	25	%	69	45	E	101	65	e
6	06	Ctrl-F (ACK)	38	26	&	70	46	F	102	66	f
7	07	Ctrl-G (BEL)	39	27	'	71	47	G	103	67	g
8	08	Ctrl-H (BS)	40	28	(	72	48	H	104	68	h
9	09	Ctrl-I (HT)	41	29	)	73	49	I	105	69	i
10	0A	Ctrl-J (LF)	42	2A	*	74	4A	J	106	6A	j
11	0B	Ctrl-K (VT)	43	2B	+	75	4B	K	107	6B	k
12	0C	Ctrl-L (FF)	44	2C	,	76	4C	L	108	6C	l
13	0D	Ctrl-M (CR)	45	2D	-	77	4D	M	109	6D	m
14	0E	Ctrl-N (SO)	46	2E	.	78	4E	N	110	6E	n
15	0F	Ctrl-O (SI)	47	2F	/	79	4F	O	111	6F	o
16	10	Ctrl-P (DLE)	48	30	0	80	50	P	112	70	p
17	11	Ctrl-Q (DC1)	49	31	1	81	51	Q	113	71	q
18	12	Ctrl-R (DC2)	50	32	2	82	52	R	114	72	r
19	13	Ctrl-S (DC3)	51	33	3	83	53	S	115	73	s
20	14	Ctrl-T (DC4)	52	34	4	84	54	T	116	74	t
21	15	Ctrl-U (NAK)	53	35	5	85	55	U	117	75	u
22	16	Ctrl-V (SYN)	54	36	6	86	56	V	118	76	v
23	17	Ctrl-W (ETB)	55	37	7	87	57	W	119	77	w
24	18	Ctrl-X (CAN)	56	38	8	88	58	X	120	78	x
25	19	Ctrl-Y (EM)	57	39	9	89	59	Y	121	79	y
26	1A	Ctrl-Z (SUB)	58	3A	:	90	5A	Z	122	7A	z
27	1B	Ctrl-[ (ESC)	59	3B	;	91	5B	[	123	7B	{
28	1C	Ctrl-\ (FS)	60	3C	<	92	5C	\	124	7C	
29	1D	Ctrl-] (GS)	61	3D	=	93	5D	]	125	7D	}
30	1E	Ctrl-^ (RS)	62	3E	>	94	5E	^	126	7E	~
31	1F	Ctrl-_ (US)	63	3F	?	95	5F	_	127	7F	DEL